

User's Manual

产品使用手册

產品使用手冊





— 01 —

INDEX/目录/目錄

English Version / 简体中文版 / 繁體中文版	
1. Installation Instructions	3
电源安装指示说明	£
電源安裝指示說明	7
2. Power Connectors	9
电源接头种类	
電源接頭種類	
Appendix I Warranty Card1	1
附录一维修保证规定1	1
附錄一 維修保證規定1	
Appendix II Guaranty Card1	d
附录二 电源供应器保证书1	į
附錄二 電源供應器保證書1	ŧ

Installation Instructions

Power Supply Installation

- Please make sure the AC Input Voltage Select Switch at the right position (115V / 230V) correspond to the power voltage given in your environment. (In case of auto-ranging power supply, input voltage checking is needless.)
- Position the power supply into the computer chassis and secure it with screws provided.
- Attach the 20-pin / 24-pin ATX/EPS Main power connector to the 20-pin or 24-pin connector on motherboard.
- Attach the 4-pin/8-pin +12V power connector to the 4-pin / 8-pin
 Pentium 4 connector on motherboard.
 Connect the 5-pin serial ATA connector to the mainboard or the
 - hard disk drive (it depends on the computer system construction).

 6. Attach the 5 1/4* 4-pin peripheral connectors to the peripherals.
 - 7. Attach the 3 1/2* 4-pin floppy drive connector to the floppy.
 8. Attach the 3-pin fan monitor control connector to the 3-pin
 - connector on motherboard. (it all depends)

 9. Replace the computer cover and secure by screws. Plug-in the
 - power cord into the power supply receptacle.

 10. Switch on the "I/O" switch of power supply to "I" status, and then turn on the computer.

Notes

Once the power switch on the back of the power supply is turned on, the on/off function of the power supply is controlled remotely through the motherboard. (Remove ON-OFF)

Installation Instructions

Power Supply Removal

 Switch off the "I/O" switch of power supply to "O" status, and then unplug the power cord from the power supply receptacle.

Remove the cover from the computer chassis.
 Disconnect all power connectors from motherboard, peripherals and filency.

 Remove the 4 screws that secure the power supply to the chassis and slide the power supply out.

Trouble-shooting

If the power supply functions abnormally, please make sure to check following items.

receptacle.

2. Please check whether the "I/O" switch of power supply switches

 Please check whether the AC Input Voltage Switch (115V / 230V) selects and sets on power supply correspond to the power voltage given in your environment.

 Please check whether all power connectors attach to proper direction with motherboard, peripherals and Floppy.

5. Please turn on and off the power supply several times, and make sure that the intervals to be at least 5 minutes.

 If the power supply still can't function after above checking, please send it back to your retailer, distributor, or seventeam service center within 3 years after purchase.
 Alon-Technician is allowed

Non-Technician is allowed.

Caution:

Incorrect installation of the connectors could damage your PC.
Under no circumstances shouldn't the power supply cover be opened.
There are dangerous high voltages inside power supply.

Refer all difficulties to Seventeam Electronics Co. Ltd.

电源安装指示说明

电源供应器的安装

开始使用。

- 将电压切换开关(115V/230V),切换在正确的电压设定之下。(由压自动切换之由源供应器则不需再切换)
- 将电源供应器装入计算机中,并以所附的螺丝领上、锁紧。
- 紧。 3. 将 ATX/EPS 主机板用之 20-PIN / 24-PIN 电源连接插头连
- 接到 ATX/EPS 主机板上之 20PIN/24-PIN 连接器上。 4. 路 ATX/2V 用之 +12V 4-PIN/8-PIN 由海海接插场连接到
- ATX12V PENTIUM4主机板上之4-PIN/8-PIN连接器上。
- 将6-PIN SERIAL ATA电源端子连接到主机板或 硬碟(装系统支援)。
- 使條(稅系院文俊)。
 6. 將51/4"之4-PIN外間设备电源连接插头连接到相关使
- 用外围设备之4-PIN连插窗上。
 7. 第3 1/2" 之 4-PIN軟式磁盘电源连接插头连接到軟盘机之
- 将31/2"之4-PIN软式磁盘电源连接插头连接到软盘机之 4-PIN连接跟上。(需视主机板支持)
- 將3-PIN风扇监控电源连接插头连接到主机板上之3-PIN 连接器上。
- 重新盖上计算机外壳,用螺丝将计算机机壳锁梁,并将 由源绝级上由原供应源的格型。
- 电源线插上电源供应器的接头。 10. 烙电源供应器上之 VO 开关切 "I" 的位置开启电源,即可

附注:

当电源供应署背后的电源开关处于"ON"的状态下时, "ON-OFF"的功能由主机板来控制。

电源安装指示说明

电源供应器的拆卸

- 将电源供应器上之I/O开关切在"O"的位置关闭电源,并 将电源供应器上接头之电源线拔下。
 据下计算机从率。
- 3. 将所有与主机板、其循外围设备及软盘机上之电源连接
- 4. 将电源供应器固定在计算机上的螺丝松动,再将电源供

简易故障排除

- 若电源供应器无法正常运作。请检查下列事项: 1. 请检查电源供应器与电源线易声确实连接。
- 请检查电源供应器上之"I/O"开关,是言置于"I"的位置上。
 请检查电源供应器上之电压切换开关(115V/230V),是否
- 置于正确的电压位置上。
 4 博检查院有与主机板、其框机图设备及整件机上由资本
- 请检查所有与主机板、其他外围设备及软盘机上电源连接插头是否有插反。
- 讀重复开启与美丽"I/O"开美动作数次,每次动作间隔需 至少五分钟以上。
 美上绘台客裏面宗成后,由源他应题仍旧子绘正常设作。
- 6. 若上还检查事項完成后,电源供应器仍旧无法正常运作, 请于保固期间内,将本电源供应器遏回零售商、经销商、 或七盟维修服务中心。
- 消务必携带此使用说明书,并于电源供应器保证书上记载购买日期及盖有销售店店章,于保固期间内,送回零售套、经管商、或七盟维修服务中心。

注意:

不正确的转换线安姜,将会损坏你的计算机。 无论在任何情况下,电源供应器的机壳必不可开启, 内有份验高由压。率有任何疑问,该由本公司法律。

建源安装指示照明

量源供离器的穷裝

- 1 越黄原初施型型(115V/930V), 初施在正確的實際 如京中下。
- (電壓自動切換之電源供應器則不需再切換) 9 越营海经海渠营入营税由, 放水经验补偿效益上。
- 44 % . 3. 終ATX/EPS主権框用之20-PIN/24-PIN電源連絡抽頭
- 津格利ATX/EPS主编板上之20PIN/24-PIN准格器上。
- 4. 將ATX12V用之 +12V 4-PIN/ 8-PIN電源連接抽頭線 排 和ATX12V PENTITINA 主 排 板 上之 4-PIN/8-PIN 津 排器上,
 - 5. 解6-PIN SEPIAL ATA實際線子連接刺主播線必嫌線 (排,条件,连接)。
- R 45 5 1/4" 之 4-PIN 28 海如 66 雷 28 18 46 46 26 18 18 48 48 10 相關体別調達於做之A-PIN(地址取上。
- 7. #3 1/2" ±4-PIN 較 水 咖啡 維 終 到 軟 課 機 ±4-PIN 換 14 22 h .
- 8. 据3-PIN服内数检索源法结构领法结别未编据上之
- 3-PIN除株器上 · (食器主糖等多級) 9. 重新蓋上電腦外殼、用螺絲將電腦機從緬緊、並將
- 香港拉納上香港供用型的技術。 10. 將電源供應器上之 I/O 開闢切"I"的位置開啓電源:
- No WE WILLIAM AN IN .

Mittel: 當電源供應器背後的電源開闢應於"ON"的狀態下時,

"ON-OFF"的功能由主播部争抢制。

雪源供顾器的拆卸

1. 終電源供應器上之1/0周闡切在"0"的位置關閉電源 並將電源供應器上接頭之電源線超下。

簡易故障排除

器上之重壓切換期間(115V/230V),

期内,越去香酱健康製品回食住 退回素性病、蜂结病、或止明翰体服務中心。

注意:

由有身势主要最,其有红红鲜明,接向主众引性物。

2 Power Connectors/电源接头种类/電源接頭種類



- 09 -

For Car I had 12



Appendix I Warranty Card

Free of Charge: Within 2 years from purchased date.
1.DDA: We offer in-30 days free exchange warranty for the goods ill defective.
2.RMA: 24 months service free warranty under normal use and oceration.

Repair fee : out of warranty.

- Seventeam has the rights to charge repairing fee under following conditions:

 1. Gaused by abnormal use, including improper connecting with other machines, improper vortage setting, over specification caused by other utilities.

 2. The newer appears and its arrisk number (abs) has been removed, or the newer.
- supply has been modified by customers themselves.

 3. The damage was caused by customer through delivery.

 4. The damage was caused by funder store, burrians, fined and burrians.
- The damage was caused by triunder, storm, nurricene, nood, earthquase fire and all out of control factors etc....
 Customer should sign purchase date on the warranty card when purcha-
- sing.

 6. Seventeem has the rights to refuse to repair the defective item from the date of our have over 5 years.

Name/Company	
Purchase date	
E-mail	
Address	

附录一 维修保证规定

免費维修范围

新品在正常使用状况下30天之相发生故障,将以新品更换。
 自助买目期起3年内,非天支人娲、在正常使用下来拆制造序号对杀而故障者。享有三年免费连维服务之保围。

付费维修范围

在保闭期间内有下列记载事项之一者,或在保证期间外 2-3年內關 維修者,關係本公司規定的效應性服务费用,數值原值。

查找至,所依条公司规定都该准算服务期间,教育原证。 每过至年之维修品等,得拥信况需定员资准修。 上现实产品参加证确存不力。或长有因常规矩阵高速之故编表、依然正在本产品模械

內內与發問我都不關則用。除入也民切換補致。或因於他輔品所造成之故樂者。 2. 於判定已在本公司以外处,能不当改論故鄉唯,或包行司本产品內括下等持律維及更 兼官。

遵任宣体改之情形明。

购买者姓名	
购买日期	
E-mail	
炮 址	

附錄一 维修保證規定

	单络花園			
1.	新品在正言	使用取见下:	30天之内發生故障, 彈以斷	品更换。
2.			非天英人偶,在正常使用下	
	序號対係的	赴除者,享;	有三年免费维修服務之保困	
	超過三年之	雄樣品,動作	比付料更接費用 ·	

解胃を他名 106 胃 11 20 E-mail

Appendix II Guaranty Card

Seventeam Electronics Co.,Ltd Guaranty Card

Model Name

Serial Number	
Purchasing Date	Date Month Year

Signature

Invalidation Without Signature

Seventeam Electronics Co., Ltd.
2F,No. 33-35, Lane 167, Sec. 1, Tung Ho E . St., Talpei, Talwan
Tel:(886) 2-2882-9050 / E-mail:sps@seventeam.com.tw

only and all products subject to change without notice.

Other names and brands may be claimed as the property of others.

附录二 电源供应器保证书

七盟电子工业股份有限公司

电源供应器保证书

GRE NO THE	de.	H	В
	4	"	ORKUMMAN

未盖店章无效

本保证书只限于中国大陆地区有效 标两黄红领北岸工业区七至电子厂

Tel:(0789)8982-1007 / €-mail: sps@yaverisam.com.h 本公司拥有对产品转改之权材。如有妥均,如不另行通知,从实物为律。 凡出现在本日录中的广商名称及使册商标图为该公司所有。

附錄二 電源供應器保證書

七盟電子工業股份有限公司

製造型號				
林贺日期	4	Я	В	

未蓋店章無效

k 保證書只限於台灣地區使用有效

Tel:(886) 2-2882-9050 / E-mail:sps@seventeam.com.tw 本公司總有對處品勞政之權利、如有變動、忽不另行場知,以實動為原率、 尼出現在未日難中的藏商名稱及故母與聯帶為效公司所有。



Seventeam Electronics Co., Ltd. 2F.No. 33-35, Lane 167 ,Sec., 1.

Tung Ho E . St ., Talpei, Taiwan TEL: +886-2-2882-9050 (Rep) FAX: +886-2-2882-8230-1 http://www.seventeam.com.bv

Dong Guan Seventeam Electronics , Ltd. Company

Bei An Village , Hueng Jiang Town Dong Guan City, Guan Dong, China TEL: +86 769 8362 1007 FAX: +86 769 8362 1006 http://www.seventsem.com.by E-mail:spe@seventsem.com.by

七豐電子工業股份有限公司

台北市士林區通河票街一股167億35號2樓 TEL: +888-2-2882-9050 (Rep) FAX: +886-2-2882-6230-1 http://www.seventeam.com.tw E-mail:sps@seventeam.com.tw

東莞七盟電子有限公司

中國展東省東莞市黃江鎮北岸工業區 TEL: +85 759 8362 1007 FAX: +86 769 8362 1006 http://www.seventeam.com.bv E-mail:sps@seventeam.com.tw

2006.07.31



